

Breeze Series Control Panel: Error Codes & Fixing Common Errors

Error Number	Meaning	Solution
8	Emb Light Not on but Pull Bar	Need to confirm design on screen
12	Stop Not in Place	Tap blue 100 icon on home screen; See page 2
13	Frame over border	Frame out of sewing field – Turn off and manually move with hands to center.
18	Color changing half rotation abnormal	Adjust by turning the handwheel by hand; see page 4
19	Needle position abnormal	See page 4; turn color change knob by hand until a needle number appears on the home screen
169	Spindle Drive Error	1. See page 3
26	Trimming not in place	1. Turn trim motor knob counter clockwise until it stops 2. Take off needle place to ensure the moveable knife is tucked under the black fixed knife See page 6 for more details

12: Stop Not in Place - (yellow slash over the 100 icon)



1. Clear the error (Press the arrow going out the door)



2. Press the 100 Button on the Control Panel (This will recycle the machine back to 100)

If no, push in the black knob on the right of the machine and turn counter clockwise until you reach 100 (Look in Sightglass to see the degree wheel)

169: Spindle Drive Error- (yellow slash over the 100 icon on the control panel)



1. Clear the Error (Press the arrow going out the door on the pop-up)
2. Manually rotate the degree wheel using a 5mm allen wrench until you reach 100 - Look through the eye glass to see what degree you are on - the yellow slash over the 100 icon on the top left of the control panel should go away.
3. Turn the machine off



4. Turn the machine back on and push the 100 icon on the control panel.


19: Needle Position abnormal



Needle icon at the top of the control panel will not have a number next to it (see picture)




Clear the Error - Press the arrow going out the door




Turn the black knob on the right side of the machine until a number appears next to the needle on the top right of the control panel

26: Trimming Not in Place-moveable knife is stuck out of position

1. Take the needle plate off by removing the two flat head screws



2. With the machine turned off, push the moveable knife back with your finger until it is tucked under the fixed knife



Knife in proper home position:

