


## D Series Wide Control Panel: Error Codes & Solutions

| <b>Error Number</b> | <b>Meaning</b>                                      | <b>Solution</b>  |
|---------------------|---|--|
| EC08                | Pll bar   | Need to confirm design on screen   |
| ED09                | Back to the beginning, then pull backward bar again | The operating error.   |
| EC11                | No such design in memory                            | Select another design.   |
| EC12                | Main shaft not stopped in position                  | See page 2   |
| EC13                | Frame over border                                   | Frame out of sewing field – Turn off and manually move with hands to center.   |
| EC14                | Part of memory lost                                 |  |
| EC16                | Sep motor   | <ol style="list-style-type: none"> <li>1. Check mechanical transmission.</li> <li>2. Check X Y motor.</li> <li>3. Check X Y driver.</li> </ol>           |
| EC17                | Color changing overtime                             | <ol style="list-style-type: none"> <li>1. Check the color motor. Check motor driver board PC501/PC502.</li> <li>2. Check the sensor.</li> </ol>          |
| EC18                | Color changing half rotation abnormal               | Adjust by turning the handwheel by hand.   |
| EC19                | Need position abnormal                              | See page 4   |
| EC20                | Main motor overtime                                 | See page 3   |
| EC21                | Color changing out                                  | "Needles" parameter setting must equal to the machine's actual needles. 9 or 12 or 15.   |
| EC26                | Trimming not in position                            | Check whether the detection sensor is damaged.   |
| EC41                | Files not in disk                                   | <ol style="list-style-type: none"> <li>1. Try again.</li> <li>2. Restart machine and then try again.</li> <li>3. Execute "Clear All Designs".</li> </ol> |
| EC42                | Disk dir full                                       | Delete some designs to free memory.  |
| EC43                | Disk space full                                     | Delete some designs to free memory.  |
| EC44                | File distribution list error                        | Execute "Clear All Designs".   |
| EC45                | Dir error   | Execute "Clear All Designs".   |
| EC208               |   | The same method as EC20.   |

**EC12: Main Shaft Not in Stop Position** - (red slash over the 100 icon on top left on Control Panel)




1. Clear the error (Press the red X on the pop-up menu)



2. Press the 100 Button on the Control Panel  
(This will recycle the machine back to 100)

If no, push in the black manual knob on the right of the machine and turn counter clockwise until you reach 100 (Look in Sightglass to see the degree wheel)

**EC20: Main Motor Overtime** - (red slash over the 100 icon on top left on Control Panel)



Clear the Error (Press the Red X on the pop-up Menu)


1. Manually turn the black knob (Push in and turn Counterclockwise until you reach 100 - Look through the Sightglass to see what degree you are on - the red slash over the 100 icon on the top left of the control panel will go away)

2. Turn the machine off




3. Turn the machine back on and push the 100 button on the lower portion of the control panel.

**EC19: Needle Position abnormal** - (The needle icon at the top of the control panel will show 0)



Clear the Error - Press the Red X



Behind the head on the right side of the machine - silver knob.

Turn the knob extremely slow left or right until the 0 changes to a number

(If you turn the knob to fast it will not register a needle number)



It does not matter the needle number it shows because once you push start it will go to the needle you programmed for your color change.