




## Oiling Points For 1201 Echo, HM/D-1501c5, HM/D-1502c5




**Oil each take-up lever spring once daily.**



**Oil each felt pad between needle arms once daily.**



**The rotary hook should be oiled after every 4 to 6 hours of use. Place oil in the groove where the hook rotates in the basket.**



**Maintain oil in wick container at half full.**



**Oil hole behind needle plate once daily.**